

# Assembly Instructions



## Safety Instructions

- Keep all packaging away from children. Dispose of the packaging in accordance to the regulations of local authorities.
- Whilst all care has been taken to remove sharp edges, care must be taken when cleaning or handling the cupboard to prevent risk of injury from exposed metal edges.
- **Safe working load: 20kgs per drawer**

## Product Description

960(H) x 700(W) x 600(D)mm

## Assembly

1. Remove all protective film from the parts, taking care to avoid scratching the surfaces.
2. Turn the unit on its back (Fig. 1).
3. Attach each foot using the plate and bolts supplied (Fig. 2).
4. Turn the unit on its legs (Fig. 3). The unit is now ready for use.



**Note: It is recommended that the cupboard is attached to the wall, with suitable fixings (not supplied), using the 2 mounting holes on the back of the upstand.**

## Cleaning, Care & Maintenance

- Before using for the first time the cupboard should be cleaned thoroughly.
- Clean the cupboard regularly using a cleaning agent suitable for use with stainless steel.
- Always remove cleaning agent residue. This can discolour the surface of the cupboard.
- Never leave the surfaces damp as this can cause discolouration.

